



SERVICE BULLETIN

Service and Maintenance manual N° ALL

Bulletin N° 006/Jul/10

Equipment affected:

All ISP manufactured products including Lifejackets and Bladder Assemblies fitted with **HALKEY ROBERTS ORAL TUBES**

Reason for issue:

New oral tube valve design by **HALKEY ROBERTS** with a shorter valve travel

Materiel required:

Oral tube adaptor, ISP part number 70-ISP-SVR-009

This bulletin is effective:

From: Immediate
To: Until Further Notice

Instruction:

Please review this service bulletin and circulate as deemed appropriate to all service personnel.

When inflating and deflating ISP lifejackets during a service and the oral tube has the new style Halkey Roberts green coloured valve core fitted (Photo 1), the existing oral tube adaptor from ISP with the part number 70-ISP-SVR-004 **must not** be used. A new universal oral tube adaptor with the ISP part number 70-ISP-SVR-009 is available from ISP which should be used. The new oral tube adaptor is compatible with the new oral tube and oral tube valve core, and is also suitable for use with all current oral tubes and oral tube valves used in ISP products except products where a Halkey Roberts Twist Lock valve has been fitted.



Photo 1

Authorised by Name (print) : R. Palin

Signature : 

Position : Projects Manager

Date : 15th July 2010

All queries relating to this Service bulletin should be addressed to: Technical Dept,
International Safety Products L^{td} Orrell mount, 159 Hawthorne Road, Bootle, Merseyside. L20 6JU. U.K.

Telephone: +44 (0)151 922 2202

Facsimile: +44 (0)151 922 5874